



yodeck

Quick Setup

Contents of Yodeck Player Kit



▶▶ Yodeck Player

▶▶ Micro-HDMI to
HDMI Cable



▶▶ Power Supply

Meet the Yodeck Player



**Use only the Left
Micro HDMI port**

1. USB-C Power Port
2. Micro HDMI Port
3. Audio Port
4. 4x USB Ports
5. Ethernet Port

Installation and Connection

STEP 1 - SCREEN CONNECTION

Connect the Yodeck Player to your screen with the Micro HDMI cable you found in the package.

Only use the Left Micro HDMI Port on the Player.



STEP 2 - NETWORK CONNECTION

2a - FOR AN ETHERNET CONNECTION

Connect the Yodeck Player to your Network by plugging an Ethernet cable (which is not included in the package) into the Ethernet port in the Player.

If you are using a WiFi connection go to section 2b.



2b - FOR A WIRELESS (WIFI) INTERNET CONNECTION

If you have an Ethernet connection, you can initially use it to configure your Player's WiFi through the Yodeck Portal. If not, you can configure it as follows:

- **Connect a keyboard** to a USB port of the Player
- Press **Ctrl+Alt+F12** (all 3 keys together)
- Type "user" and the Player's password, default is **signagepassword**
- **Follow instructions on screen** to connect to a WiFi network
- Make sure you configure the **exact same settings** on the Yodeck Portal as well



How to use the WiFi wizard

Scan QR Code for

YouTube Video Tutorial

or visit yodeck.link/wifi

STEP 3 - POWER CONNECTION

Plug the USB Type-C end of the power adapter cable into the USB Type-C port on the Player and plug the power adapter into a power source.

The Player will start to work automatically.



STEP 4 - REGISTRATION

Playback should start after a few minutes.

If a Registration Code is displayed, you will need to use that in the Yodeck Portal to pair the Player with your account.

Having Trouble?

Is your screen not showing anything?

Make sure your screen is on and that the screen input is set to the correct source (e.g. HDMI), which is the port you connected your Player to.

Boot-up seems to be stuck on the Yodeck logo?

Wait at least 10 minutes before worrying.

Is the Player still appearing as "Offline"?

Try using an Ethernet cable instead of WiFi. Or unplug the Ethernet cable, wait 10 minutes and plug it in again.

Still not working?

Avoid rebooting constantly, it might do more damage than good, just let us know and we will help you out.



Need more help?

Scan QR Code or visit
our support page

<http://yodeck.link/help>